


# 512 Hz Miniature Transmitters


All items on this page shown actual size.

## FM-05

Maximum range:  
5 feet in cast iron,  
7 feet in nonmetallic lines




NOTE: A Drophead is *required* to be used with this generation of FM-05s (available for 3/16" or 1/4" push rods)



## FD-10

Maximum range:  
10 feet in cast iron,  
15 feet in nonmetallic lines



Use it by itself, taped to a push rod or in a spring carrier



or use a Dropcap to attach it to the end of a tape or rod (available for 3/16" or 1/4" push rods)



**Ardy sez:**

- A couple turns of tape where the drophead or dropcap attaches to your push rod will keep it from unscrewing in the line and ruining your day!
- The FM-05 will not survive being attached to a power snake, and no warranty will apply if you use one this way. The FD-10 can be attached to a power snake using a spring carrier.
- The button on the battery always goes in first, toward the transmitter body.
- These transmitters do not float, and you will not get one back if you flush it!



**800-541-9123**