



How to Use Flushable Transmitters

These transmitters turn on and off with the push button:

- To activate, hold the button down until you see a solid *yellow* (ATP-12) or *blue* (FTP-8) LED light. Release the button and it will begin to flash. Now it is ready to use.
- To turn it off, hold the button down until you see the solid LED again, then let go and it will go out.
- When the LED turns from its standard color to *red*, the transmitter is in its last hour of operation. You may continue to use it, but when that last hour is up it will no longer turn on. This will prevent using a dead transmitter for a locate.

Always test a transmitter before you send it down the line! We will gladly replace any transmitter that arrives to you dead, but that doesn't help much if you send a dead one down the line and don't have a spare.

These transmitters are designed to be flushed, with or without a string or line attached to the eyelet. Although they often work well when taped to a push rod, we cannot warrant transmitter failures when used this way.

Prototek Corporation

Poulsbo, WA 98370

(800) 541-9123



How to Use Flushable Transmitters

These transmitters turn on and off with the push button:

- To activate, hold the button down until you see a solid *yellow* (ATP-12) or *blue* (FTP-8) LED light. Release the button and it will begin to flash. Now it is ready to use.
- To turn it off, hold the button down until you see the solid LED again, then let go and it will go out.
- When the LED turns from its standard color to *red*, the transmitter is in its last hour of operation. You may continue to use it, but when that last hour is up it will no longer turn on. This will prevent using a dead transmitter for a locate.

Always test a transmitter before you send it down the line! We will gladly replace any transmitter that arrives to you dead, but that doesn't help much if you send a dead one down the line and don't have a spare.

These transmitters are designed to be flushed, with or without a string or line attached to the eyelet. Although they often work well when taped to a push rod, we cannot warrant transmitter failures when used this way.

Prototek Corporation

Poulsbo, WA 98370

(800) 541-9123